2.10 Firmware Update with USB Drive

Important:

- 1. This document is applicable to NovoTouch EK series, including NovoTouch EK2, EK3, and EK4 series.
- 2. Each EK model has its own upgrade package. Please make sure you download the correct package for your model. Using a wrong package could make your NovoTouch unable to boot up.

Step-by-step instructions:

- The upgrade package is stored in a folder called "upgrade_811" / "upgrade_9950" / "upgrade_3588". When you receive the firmware upgrade package, typically you need to unzip it first and then copy folder "upgrade_811" / "upgrade_9950" / "upgrade_3588" onto a USB disk. You should see the following file/folder structure on the USB disk. (The following picture shows how it looks for EK2 series.)
 - For EK2 series, the folder should be "upgrade_811"
 - For EK3 series, the folder should be "upgrade_9950"
 - For EK4 series, the folder should be "upgrade_3588"

File Home Share View							
← → ✓ ↑ 🔒 > This PC > KINGSTON (E:) > upgrade_811			ٽ ~	Search upgrade_811	م		
> 🖆 Documents	^	Name	Date modified	Туре	Size		
> 🕂 Downloads		allupgrade_v811.bin	4/6/2020 1:01 PM	BIN File	3,155,387 KB		
> 🁌 Music		📓 allupgrade_v811_MD5.txt	4/6/2020 1:02 PM	TXT File	1 KB		
> 📰 Pictures		📔 cvte_checksum_img.txt	4/6/2020 1:01 PM	TXT File	0 KB		
> 📮 Share (WIN-73U319U0MNB (ESS Test Server		MCU.bin	4/6/2020 1:02 PM	BIN File	93 KB		
> 🛛 Videos		MCU.md5	4/6/2020 1:02 PM	MD5 File	1 KB		
Local Disk (C:)		<pre>software_check_table.txt</pre>	4/6/2020 1:02 PM	TXT File	1 KB		
Local Disk (D:)		VERSION_INFO.txt	4/6/2020 1:02 PM	TXT File	1 KB		
 KINGSTON (E:) 							
System Volume Information							
upgrade_811	~						
7 items							

EK2 example

📙 🛃 🖡 🗧 upgrade_35	88			– 🗆 X						
File Home Share View ? ? ?										
\leftarrow \rightarrow \checkmark \uparrow 📜 \Rightarrow This	✓ Search upgrade_35									
	Name	Date modified	Туре	Size						
	817.bin	8/21/2024 10:29 PM	BIN File	38 KB						
✓ Signature This PC	817_Version.txt	8/21/2024 10:29 PM	Text Source File	1 KB						
> 📙 3D Objects	💿 allupgrade_3588_64G_8G_90.img	8/21/2024 10:29 PM	Disc Image File	3,737,157 KB						
> 🔚 Desktop	🖹 allupgrade_3588_64G_8G_90_MD5.txt	8/21/2024 10:30 PM	Text Source File	1 KB						
> 📔 Documents	CODE_VERSION_INFO.txt	8/21/2024 10:29 PM	Text Source File	1 KB						
> , Downloads	LT8711UXE1_EXTBOARD.bin	8/21/2024 10:29 PM	BIN File	33 KB						
> 🌗 Music	LT8711UXE1_MAINBOARD.bin	8/21/2024 10:29 PM	BIN File	33 KB						
> ╞ Pictures	SENSOR.bin	8/21/2024 10:29 PM	BIN File	48 KB						
> Videos	SENSOR.txt	8/21/2024 10:29 PM	Text Source File	1 KB						
I Local Dick (C)	SENSOR_GD32F303.bin	8/21/2024 10:29 PM	BIN File	69 KB						
	SENSOR_GD32F303_version.txt	8/21/2024 10:29 PM	Text Source File	1 KB						
V SB Disk (U:)	SENSORBOX.bin	8/21/2024 10:29 PM	BIN File	71 KB						
📙 upgrade_3588	SENSORBOX.txt	8/21/2024 10:29 PM	Text Source File	2 KB						
> 🥩 Network	software_check_table.txt	8/21/2024 10:29 PM	Text Source File	2 KB						
	vendor_boot-debug.bin	8/21/2024 10:29 PM	BIN File	50,946 KB						
	🖹 version.txt	8/21/2024 10:29 PM	Text Source File	20 KB						
16 items										

EK4 example

- Power down
 NovoTouch panel.
- Insert the USB disk into the USB port at the front panel of NovoTouch panel.

- Press-and-hold button POWER until the LED flashes red and blue quickly, indicating the upgrade process is started. Please do NOT remove the USB disk during this process.
- A progress bar is shown to display the completion percentage. Once it gets to 100%, the NovoTouch will restart automatically. During this first-time bootup, it will take a bit longer to perform some additional post-processing.
- Once it fully boots into Android home screen, the firmware upgrade is completed. Now you can unplug the USB disk.