

1.1 Windows Setting

NovoConnect Stage is an all-in-one meeting collaboration solution which runs on Windows OS system. Before you start to install this software. Please confirm your OPS environment matches the hardware and software requirement in below tables.

Name	Hardware Requirement
OS System	Windows 10+
CPU	Intel i5 (12th-Gen)
RAM	8 GB
Storage	4 GB
Aspect Ratio	16:9 / 21 : 9
Display Resolution	3840 * 2160 / 5210 * 2160

Hardware requirement

Name	Software Requirement
Calendar Type	Microsoft Outlook Calendar
Mirroring Software	NovoConnect Software (Windows & MAC) / Airplay
Video Conferencing Software	Microsoft Teams / Skype / Zoom

Software requirement


After installed NovoConnect Stage, please follow below steps to set up Windows display resolution and enable touch keyboard.

Set up Windows display resolution

Please according your Windows OS version to set up

- Windows 10


1. Go to “Settings” > “Display”
2. Select scale to 150%
3. Select display resolution



Set up display resolution in Windows 10

▪ Windows 11

1. Go to “Settings” > “System” > “Display”
2. Select scale to 150%
3. Select display resolution




Set up display resolution in Windows 11

Enable touch keyboard

If your panel has touch function, please follow the steps to enable touch keyboard. Please according your Windows to set up

▪ Windows 10


1. Go to “Settings” > “Devices” > “Typing”
2. Enable touch keyboard



Enable touch keyboard in Windows 10

▪ Windows 11

1. Go to “Settings” > “Time & Language” > “Touch keyboard”
2. Enable touch keyboard



Enable touch keyboard in Windows 11