
## 2.2 How to Perform Firmware Upgrade

- 1. Download and Install the LauncherPlus Pairing Utility from the link:
- 2. Once the installation is completed, launch the LauncherPlus
  Pairing Utility
- 3. Connect the LauncherPlus to your laptop USB-C port. The LED indicator color should be green blinking.



4. Click the **Details** button.

## LauncherPlus



Details >

5. Click the **Check for update** button

Current Version 1.0.0.3X (20220101)

Check for update

Fiemware version is up to date

6. Click the Upgrade now button if available

Current Version 1.0.0.3X (20220101)

**Upgrade** now

New firmware version 1.0.0.3X (20220808)

7. Refer to the following table for the upgrading status:

Status	LED Color
FW Downloading	Blue & red — Blinking
LauncherPlus is being upgraded.	Green Blinking