


2.2 How to Perform Firmware Upgrade

1. Download and Install the **LauncherPlus Pairing Utility** from the link:
2. Once the installation is completed, launch the **LauncherPlus Pairing Utility**
3. Connect the LauncherPlus to your laptop USB-C port. The LED indicator color should be green – blinking.



4. Click the **Details** button.



5. Click the **Check for update** button



6. Click the **Upgrade now** button if available



7. Refer to the following table for the upgrading status:

Status	LED Color
FW Downloading	Blue & red – Blinking
LauncherPlus is being upgraded.	Green Blinking