



2.6.3.3 Video In Background

When you select video in () for a background design, an editing menu will appear for the type video input. Follow the steps below to make video from an HDMI device or a webcam video stream the background:



Content Type ✕

1 HDMI

Video

2 Display in High Resolution

Others:

Channel ID: Background-1

3

1. Select either **HDMI** or **USB Camera** depending on the type of device connected.
2. Check **Display in High Resolution** have the video be shown in High Resolution
3. Click **Save** to finish configuring the background settings.

