


3. Software Features

Studio Express is designed to support various screen dimensions, such as mobile phones, tablets, and laptop computers. For example, the same “Welcome aboard” page can fit a mobile phone screen and a laptop computer screen properly. The following two pictures show how it looks on both screen sizes. This flexible design makes it extremely accessible to users.

The remaining sections of this chapter will describe the key features in details. To make it concise, we only use mobile-phone screenshots for illustration from here onwards.



The screenshot shows the 'Welcome aboard!' screen of the Studio Express mobile app. At the top, the status bar shows the time 9:41 and signal/battery icons. Below the status bar, the Vivitek and NovoDS Studio Express logos are displayed. The main heading is 'Welcome aboard!' in orange. Below it, a message states: 'Studio Express allows you to design playlists and control signage playback directly on the device. (There is no software installation.)'. A section titled 'To start, please adjust the followings to match this device's installation.' contains several settings: 'Device name' with a text field containing 'Novo-12345'; 'Screen orientation' with a dropdown menu set to 'Landscape'; 'Time zone' with a dropdown menu set to '(GMT-7:00) Pacific time'; and a 'Sync to current time zone' option with a refresh icon. Below these is an 'Access code' section with a note: 'It is recommended to set an "access code" to prevent unauthorized access to Studio Express.' and a 'Set access code' toggle switch that is currently turned on. At the bottom, there is a text input field for the access code with a lock icon on the left and a visibility icon on the right. A large orange button labeled 'Get Started →' is at the very bottom.

9:41

vivitek | NovoDS Studio Express

Welcome aboard!

Studio Express allows you to design playlists and control signage playback directly on the device.
(There is no software installation.)

To start, please adjust the followings to match this device's installation.

Device name

Novo-12345

Screen orientation : Landscape

Time zone : (GMT-7:00) Pacific time

Sync to current time zone


Access code

It is recommended to set an "access code" to prevent unauthorized access to Studio Express.

Set access code

Get Started →

“Welcome aboard” shown on a mobile phone screen



“Welcome aboard” shown on a laptop screen