

4.2.4 Boot channel

NovoTouch allows you to select preferred boot-up channel, e.g. OPS, HDMI1, HDMI2 etc..

