

4.4.2 Group Action – Change Playlist

To have all the devices in a group to change to the same playlist, follow the steps below:

1. Click on the group in the group list.
2. Click the **Change** button at the top-right of the device list.



3. In the **Filter** field, check all the Novo device types you want the playlist to play on from the group.
4. Select the playlist you want to play in the main window.
5. Click **OK**.

