
## 5.1.1 Sleep timer


This article is applicable for NovoConnect NC-X500

## **Configuring a Sleep Timer**

Step1. In the NT Settings menu, tap **Display**.



Display settings Step2. In the **Display** menu, select **Sleep Timer**.




Modes of Sleep Timer

Step3. The Sleep Timer menu will show the following options:

- Do not enter sleep mode
- Enter sleep mode after idle timeout

This item includes the following options to select: **5 minutes** / **10 minutes** / **15 minutes** / **30 minutes** / **1 hour** 

- I. After you've selected the option you want, tap Apply.
- II. Return to the display's home screen.
- III. Once the home screen has been idle for the designated amount of time, the display will enter sleep mode.



Timer selection


Always on

Allows you to set the days and time period each week when the display will be constantly on.


- i. After you've selected the days and time period you want, tap Apply.
- ii. Return to the display's home screen.
- iii. Once the designated time is past, the display will enter sleep mode.

<	Dis	play	
Resolution	Sleep Timer		
Scaling	Do not enter sleep mode Enter sleep mode after idle-timeout		
Sleep Timer	Always on	er idle-timeout	
Auto Reboot	8:00 AM - 5:30 PM   Mon . Tue . Wed . Thu . Fri		
Low Blue Light			_
HDMI-CEC			
	Apply	Cancel	

Create a schedule



Apply the Scheduler



## Successfully set up message

∷

<

>

区