

# 6.1 How to extend your screen? (Windows)

## Screen Extension for Windows Computers

Screen extension for Windows computers is a little bit complicated.

- For Windows 10 computers, a Screen Extension driver is required.
- For Windows 7 and 8 computers, no additional driver is needed.

## Install Screen Extension Driver for Windows 10

1. Download the Screen Extension driver for Windows 10

Executable version	V1.0.2	3.53 MB	<a href="#">Download</a>
MSI version – please install as admin	V1.0.2	0.74 MB	<a href="#">Download</a>

2. Please note that you will need Admin Privilege to install a driver. Launch the Screen Extension installer and follow the on-screen instructions to complete the process.

## Turn On/Off Screen Extension in NovoConnect Software

1. Run NovoConnect Software or LauncherPlus/LauncherOne software and connect to the desired Novo device.
2. When you start projecting your screen, click the

“Screen Extension” icon to toggle between “Duplicate” and “Extend” display modes.

## Turn On/Off Screen Extension in NovoConnect Software

1. Run NovoConnect Software or LauncherPlus/LauncherOne software and connect to the desired Novo device.
2. When you start projecting your screen, click the “Screen Extension” icon to toggle between “Duplicate” and “Extend” display modes.

### LauncherPlus




Click to duplicate desktop



Click to extend desktop

## LauncherOne




Click to duplicate desktop



Click to extend desktop

# NovoConnect Software



Click to duplicate desktop



Click to extend desktop

## Tutorial Video