2.7 Use Remote Manager for installation

Launch **Remote Manager** software under the same local network with Novo device.

Go the the left topper corner, click **+Deivce** > Input the Novo device's IP address to add the device into Remote Manager table.



One the device list, click the device you want to configure, then click to go to setup.

🛛 Refresh 🛛 Total: 71 () 😝 7 😝 0 😝 64)					Search			68	ā 🖉
	•	Device Name	IP Address	rou	Activity	Device Type	Firmware Version	WI-FI M	ac Address 📤
1	\bigcirc	Novo-DE271	10.136.5.20		Idle	NovoTouch EK-II Ser	v4.1.0.1024	50:2B:73:	DD:13:0A
2	0	Novo-D831G	10.136.5.126		Idle	NovoPro	v2.7.4.422	04:E6:76:	C3:33:78
3		Novo-16016	10.136.5.17		Idle	NovoTouch LK Series	v3.1.1.284	10:D0:7A	:71:BB:47

IT can control the devices remotely, such as setup device name, remote upgrade, change system language and time zone, download log file remote for troubleshooting and so on for individual Novo device.

Novo-B5CADE271 (10.136.5.20)						
General Network Securit	ty Misc.					
Device Name	Novo-DE271	< Apply				
Model	NT-C2100-WFS0860					
Edition	Corporate					
App Version	v4.1.0.1024	🕑 Online Update				
Build Version	NovoTouch-C2100-0049					
Software Edition	C2100-WW-CORP-EDU					
Online Users	0					
O Refresh			Close			

General settings

Novo-B5CADE271 (10.136.5.20)					
General Network Security Misc.					
Wi-Fi Mode HotSpot	🔗 Configure Wi-Fi				
SSID NVC_DE271					
Wi-Fi IP 192.168.43.1	맥 Network Routing				
LAN IP 10.136.5.20					
WI-FI Mac Address 50:28:73:DD:13:0A					
LAN Mac Address C0:8A:CD:DE:E5:30					
O Refresh	Close				

Network settings



Security settings

Novo-B5CADE271 (10.136 General Network Securit								
Display								
Language	English 🔷	< Apply						
Time Zone	Pacific Time (GMT-7:00)	✓ Apply						
NTP Settings								
System Time	2020/06/30 02:02:56 PDT							
NTP Server	2.android.pool.ntp.org	≺ Apply 3 Reset						
Log Download								
	Enable Log Download	≺ Apply						
Restart Device								
	3 Reboot Now							
Configure Device								
	• Upload Configuration File							

Settings for System Language, Time Zone, NTP Server, Log File Download, Remote Reboot, Upload Config File.