


3.10 Screen Lock


The NovoTouch **Screen Lock** app allows you to activate a 4-digit screen lock password.

Step 1. Go to **More App** → tap **Settings**




Step 2. Tap **Security & privacy** to enter configuration

Step 3. Tap **Set screen lock** to set up screen lock



Step 4. Select **one of the methods to set up screen lock** , e.g., select **PIN** to set up screen lock.



Step 5. **PIN Code** is required to enter every time when power on the device. .

