

Accessories

NovoDisplay


Model name: DK431, DK551P, DK651, DK751

Ensure that all of the proper items are included with the display in the packaging. The items that should be included in the packaging are:


NovoDisplay




Remote Control with Battery




Power Cable




Wall Mount Kit (43" / 55")




Wall Mount Kit (65")




Wall Mount Kit (75")




NovoDisplay OPS Module



Antenna (x4)



Quick Start Guide



Schedule Panel ON/OFF cable (x2)

