# 2.3 NT Settings


NT Settings contains **Network**, **Orientation**, **Software Upgrade** and **Device Settings**.

The article will explain the main functions of NT Settings and guides you how is it working.

### How to enter the NT Settings

\*User will need to connect a Wired/ Wireless Mouse to NovoDisplay for the following operation.


- Click "Presentation" at the bottom-left of the screen
- Then click "Settings"



Click "Device Settings" to enter NT Settings



## NT Settings Menu



## Wi-Fi Settings

Wi-Fi Hotspot mode is factory default setting, you can change it to Connect to Wi-Fi (AP-Client), or Turn Wi-Fi off (Radio off).




Wi-Fi Hotspot mode also provide "LAN-Wi-Fi-Hotspot routing", It means, when this option is enabled, both the two network will be the same routing, if NovoConnect X700/ X900 connects both Wireless and Wired network.

#### Wi-Fi Frequency and Channel

Wi-Fi HotSpot mode provide 2.4GHz and 5GHz, they have 11 channels and 9 channels respectively. 5GHz and Channel 40 is factory default setting, you can change the frequency and channel anytime.

Select Channel			
2.4 Ghz	5 Ghz		
CH 1	CH 36		
CH 2	CH 40 🕢		
CH 3	CH 44		
CH 4	CH 48		
CH 5	CH 149		
CH 6	CH 153		
CH 7	CH 157		
CH 8	CH 161		
CH 9	CH 165		
CH 10			
CH 11			

### Upgrade



User can check the current software version here. And also if the updates available, user can perform online upgrade by tapping "Check for updates". (Internet connection is needed for the process)

## **General Settings**

<	General		
Device Settings		Remote Manager Cloud	
Room Name	DK4-Novo-C3E74	Cloud Service	ON
Log Download	OFF	Device ID SKY-ØRE	RESET
Advanced Settings		Device Status Online	
Android Settings	Set Set	Remote assist	Enabled

Here user can also perform the following settings:

#### Change the Room Name

User can change the device name for easily identifying the device or the location where the device is. This changing will also be displayed on the Home Screen.

### Enable or disable Log Download

Allows the log file to be downloaded for debugging.

### Advanced Settings (Android Device Settings)

To change Date, Time, Time Zone, Input Method, Language, Google Account. Or advanced settings for system management or maintenance, e.g. Apps management, System Security, Networking Credentials, etc.

#### Cloud Service

Toggle to enable or disbale NovoConnect Remote Management (RMC) service.

#### Remote assist

Allow this device to be controlled from NovoConnect RMC.

 $\equiv$ 

<

>

区