2.6 How to Upgrade NovoDisplay DK4 through OTA

Important: *This article is applicable to NovoDisplay series, model name as DK434, DK554, DK654, DK754, DK854.*


This section covers the upgrade process for NovoDisplay DK4 units running a software version of 6.0.1.0069 or earlier.

Please follow the instructions below to perform the upgrade.

Checking Devices Software Version:

Before starting the device upgrade process, you should check the current software version. Please follow these instructions to do so:


- On the home screen, click the **Presentation** in the bottom left corner.
- Click **Settings** to go to the **Device Setting** page.



- Navigate to the **Upgrade** section and confirm that the software version is **6.0.1.0069 or earlier**.
- If your device's software version is **6.0.1.0069 or**

earlier, please return to the home screen and continue to follow the upgrade instructions.


- If your device's software version is **newer than 6.0.1.0069**, click the Upgrade button to perform the upgrade directly.




Update the NT AppManager Software Version:

To prepare for the device software upgrade, first update the **NT AppManager** app by following these steps:


- Return to the home screen and swipe to the **Apps page**.
- Click the **NT AppManager** icon.



- Click the **Update** to begin the app upgrade.




- Once the update is completed, a **confirmation message** will be displayed on the screen.




Upgrade NovoDisplay DK4 Software Version:

Once your **NT AppManager** is up-to-date, your device is available for upgrade to the latest version. Please follow the instructions below to begin the process:


- On the home screen, click the **Presentation** in the bottom left corner.
- Click **Settings** to go to the **Device Setting** page.




- Navigate to the **Upgrade** section, click the **Upgrade** button to perform the upgrade directly.



- Click **OK** to start the upgrade process.
- The device will start the process by downloading the file, installing the new software, and then automatically rebooting.



- After the upgrade is completed, please navigate to the **Device Settings** to confirm that the software version is **equal to or newer than 6.0.2.0097**.


Upgrade
Current version: 6.0.2.0097
This is up to date.
Check for updates