


Content-Sync Schedule

Content-Sync Schedule allows you to define how you would like to update the content on the devices. There're 3 options.

1. **Manual update:** Playlist will be updated when you perform "Publish" manually.
2. **Update at [hh:mm] daily:** Playlist will be updated at [hh:mm] per a day
3. **Update every [hh/mm] starting at [hh:mm]:** Playlist will be updated every [hh/ mm], starting at [hh:mm]



The screenshot shows a 'Device Control Panel' window with a blue header and a close button. Below the header is a navigation bar with tabs: Status, Playlists, Schedule, Announcements, Content-Sync Schedule (active), Device Logs, and Publishers. The main content area is a white box with a blue border containing three radio button options for scheduling updates. The first option, 'Manual update', is selected with a green dot. The second option, 'Update at 0:00 daily', is unselected. The third option, 'Update every 15 Minutes starting at 0:00', is also unselected. Each option has a corresponding radio button and a set of input fields for time and frequency. A blue button labeled 'Content-Sync Schedule' is located at the bottom right of the panel.

For example, you have created and publish a playlist to NovoDS. You're going to update the content in this playlist everyday and want it to be updated to the device at a specific time: 1200 pm daily. Then you select the 2nd option, and specify the time as 12:00.

(Please note that, you should have the playlist ready before the specified time is reached.)

If it is set up properly, the device will play the updated content after the 12pm's content-sync is completed.