



3.12 Touch Back

When your PC or laptop screen is mirrored to the NovoTouch, your screen will be displayed in a **floating window**.


The **Control Panel** will be displayed at the bottom of the floating window for 10 seconds, then automatically hidden.








The **Control Panel** provides five additional features.



The following table has the description of each tool icon.

Icon	Functions	Description
	Size	Change projected screen size, from small/medium/large

Icon	Functions	Description
	Position	Display your screen in the desired position
	Full Screen	Display your screen from normal to full screen or from full screen back to normal
	Auto-Layout	Automatically lay out projected screen
	Touchback	This function allows you to control the projected PC/laptop
	Close	Withdraw projection