

# NovoDisplay DK4 Release Note

## V6.0.2

2025/09/26

### New Features

- Supports ErP (Energy-related Products Directive)
- Update the EDID to display Vivitek and DK4.
- Supports opening the DK4 (ND-M1000) home app menu when pressing the App Menu button on the remote control.
- Supports entering sleep mode by short-pressing the power key on the remote control.

### Enhancements & Changes

- Remove the 'Sleeping' message when DK4 (ND-M1000) enters sleep mode.
- When the DK4 (ND-M1000) loses signal, a window will appear asking whether to return to the Android source.
- The DK4 (ND-M1000) has been changed to not automatically power on when plugged in.

### Bug Fixes

- Fixed the issue where the DK4 (ND-M1000) automatically wakes up 30 seconds after entering sleep mode.
- Fixed the issue where after setting the startup channel on the DK4 (ND-M1000), the device first enters the set channel upon booting, then returns to the Android source.
- Fixed the issue where the built-in speaker produces no sound after connecting USB audio on the DK4 (ND-M1000).
- Fixed the issue where switching the Hotspot channel sometimes causes Wi-Fi to fail to detect networks.
- Fixed the issue where the DK4 (ND-M1000) cannot set the

sound output channel.

- Fixed the issue where the speaker still outputs sound after HDMI OUT is connected and audio is turned off on the DK4 (ND-M1000).
- Fixed the issue where the panel buttons on the DK4 (ND-M1000) were unresponsive.

## V6.0.1

2025/09/05

### New Features

- Portrait UI Home Screen Design, including a vertical boot animation.
- Support for vertical video playback.

### Enhancements & Changes

- Updated GMS version which in turn enables the support of Chrome and Youtube.
- Optimized the display of message “Network connection is unstable”:
  - Support for firmware upgrade via USB
  - Remove the startup wizard.
  - Change the backlight default setting to 75%.

### Bug Fixes

- Fix: Displaying “dual type” after firmware flashing.
- Fix: Hotspot being set as the default after firmware flashing.
- Fix: DK4 (ND-M1000) automatically powering on when the power cord is connected.
- Fix: Commands being unresponsive when the Baud Rate is set to 115200.
- Fix: Boot-up logo displaying Landscape when the setting is configured to Portrait.

- Fix: Input source icon showing a connected signal source when none is actually connected.
- Fix: Device sometimes failing to automatically advance to the next page after connecting to Wi-Fi in the Setup Wizard following a firmware flash.
- Fix: Device not displaying session info when the Client selects the “show session info” button.
- Fix: Incomplete display content for How-to Present when using Portrait mode.
- Fix: Device automatically starting playback after approximately 50 seconds when returning to the home screen from a third-party app or rebooting, even when Auto-Play is set to Never.
- Fix: Signage screen getting stuck and failing to switch when toggling it on/off.
- Fix: Default Playlist not playing according to schedule when using DS Schedule for playback.
- Fix: Inability to input Wi-Fi password using the remote controller.
- Fix: Device requesting a password when connecting to the Hotspot.