NovoTouch BK series User's Manual

BK1 series: BK650i / BK750i / BK860i

BK2 series: BK652i / BK752i / BK862i

1. Get to Know Your Touch Panels

- 1. What is NovoTouch BK series
- 2. Product Features
- 3. Companion Software
- 4. <u>Accessories</u>
- 2. Set Up Your NovoTouch
 - 1. Installing the Wall Mount
 - 2. <u>Get Started</u>
 - 3. Direct power on/off
 - 4. Connect your NovoTouch to your network
 - 5. <u>Setting up a Wi-Fi Hotspot</u>
 - 6. <u>Switch input source</u>
 - 7. Use Remote Manager for installation
 - 8. Firmware Update with USB Drive Model BK1 series
 - 9. Firmware Update with USB Drive Model BK2 series

3. NovoTouch Basics

- 1. <u>Home Screen</u>
 - 1. Change the wallpaper
- 2. Launch Pad
- 3. <u>Side Bar Tools</u>
- 4. <u>NovoConnect</u>
 - 1. Using Native Mirroring
- 5. <u>NT LiveReceiver</u>
- 6. <u>Browser</u>
- 7. <u>Finder</u>
- 8. <u>NT APP Store</u>
- 9. Turn WiFi off and on
- 10. Change device name

- 11. <u>Clear History</u>
- 12. <u>Whiteboard</u>
- 13. <u>Screen Lock</u>

4. Advanced Features

- 1. <u>NT Settings</u>
 - 1. <u>Sleep timer</u>
- 2. More Apps
- 3. <u>SysControl (Network-based Control)</u>
- 4. <u>RS-232 Control</u>

5. More of NovoConnect Software

- 1. <u>Screen Extension</u>
- 2. Audio On/Off and Mirroring Mode
- 3. Video and YouTube
- 4. <u>AirNote</u>
- 5. <u>NT LiveNote On-Screen Annotation & Screen-Share</u> <u>Control</u>
- 6. Sharing Files and Webpages
- 7. Voting/Polling

6. FAQs and Troubleshooting

- <u>How to use remote control to disable front buttons</u> or touch feature
- 2. <u>How to capture log</u>
- 7. Remote Manager
 - 1. Introduction
 - 2. Install Software
 - 3. Add/Remove Group Device
 - 4. Add Devices via Auto Discovery
 - 5. Configure Device Setting
 - 6. Remote Power On/Off (RDM)
 - 7. <u>Update Firmware</u>
 - 8. Configure Moderator Credentials
 - 9. <u>Server mode Remove Manager DB Server</u>
 - 10. Use Remote Manager for large deployment

8. Accessories

1. Mobile Stand VKST03