NovoTouch EK5 series User's Manual

EK5 series: EK657i / EK757i / EK867i

- 1. Get to Know Your Touch Panels
 - 1. What is NovoTouch EK5 series
 - Product Features
 - 3. Companion Software
- 2. Set Up Your NovoTouch
 - 1. <u>Installing the Wall Mount</u>
 - 2. Get Started
 - 3. Connect your NovoTouch to your network
 - 4. <u>Setting up a Wi-Fi Hotspot</u>
 - 5. Turn WiFi off and on
 - 6. Change device name
 - 7. Switch input source
 - 8. <u>Use Remote Manager for installation</u>
 - 9. Firmware Update with USB Drive
- 3. NovoTouch Basics
 - 1. Home Screen
 - 1. Change the wallpaper
 - 2. Launch Pad
 - 3. Side Bar Tools
 - 4. NovoConnect
 - 1. Using Native Mirroring
 - 5. NT LiveReceiver
 - 6. Browser
 - 7. File Manager
 - 8. NT AppManager
 - 9. Whiteboard
 - 1. <u>Simultaneous Collaboration with Dual Colors</u>
 - 10. Screen Lock
 - 11. <u>On-Screen Annotation</u>
 - 12. Touch back

13. More Apps

4. Advanced Features

- NT Settings
- 2. Advanced Feature
 - 1. Boot-up Time
 - 2. Shutdown Time
 - 3. Auto Sleep
 - 4. Boot Channel
 - 5. Wake Up By Input Source
- 3. SysControl (Network-based Control)
- 4. NovoTouch EK-5 RS-232 Control

5. More of NovoConnect Software

- 1. Screen Extension
- 2. Audio On/Off and Mirroring Mode
- 3. Video and YouTube
- 4. AirNote
- 5. <u>NT LiveNote On-Screen Annotation & Screen-Share</u>
 Control
- 6. Sharing Files and Webpages
- 7. Voting/Polling
- 8. Touchback From Projected Screen

6. FAQs and Troubleshooting

- 1. How to use remote control to disable touch feature
- 2. How to capture log

7. Remote Manager

- 1. Introduction
- 2. <u>Install Software</u>
- 3. Add/Remove Group Device
- 4. Add Devices via Auto Discovery
- 5. Configure Device Setting
- 6. Remote Power On/Off (RDM)
- 7. <u>Update Firmware</u>
- 8. Configure Moderator Credentials
- 9. <u>Server mode Remove Manager DB Server</u>
- 10. Use Remote Manager for large deployment

8. Accessories

1. Mobile Stand VKST41