NovoTouch EK5 series User's Manual

EK5 series: EK657i / EK757i / EK867i

1. **Get to Know Your Touch Panels**
    1. What is NovoTouch EK5 series
    2. Product Features
    3. Companion Software
2. **Set Up Your NovoTouch**
    1. Installing the Wall Mount
    2. Get Started
    3. Connect your NovoTouch to your network
    4. Setting up a Wi-Fi Hotspot
    5. Turn WiFi off and on
    6. Change device name
    7. Switch input source
    8. Use Remote Manager for installation
    9. Firmware Update with USB Drive
3. **NovoTouch Basics**
    1. Home Screen
        1. Change the wallpaper
    2. Launch Pad
    3. Side Bar Tools
    4. NovoConnect
        1. Using Native Mirroring
    5. NT LiveReceiver
    6. Browser
    7. File Manager
    8. NT AppManager
    9. Whiteboard
        1. Simultaneous Collaboration with Dual Colors
    10. Screen Lock
    11. On-Screen Annotation
    12. Touch back

    13. More Apps
4. **Advanced Features**
    1. NT Settings
    2. Advanced Feature
        1. Boot-up Time
        2. Shutdown Time
        3. Auto Sleep
        4. Boot Channel
        5. Wake Up By Input Source
    3. SysControl (Network-based Control)
    4. NovoTouch EK-5 RS-232 Control
5. **More of NovoConnect Software**
    1. Screen Extension
    2. Audio On/Off and Mirroring Mode
    3. Video and YouTube
    4. AirNote
    5. NT LiveNote – On-Screen Annotation & Screen-Share Control
    6. Sharing Files and Webpages
    7. Voting/Polling
    8. Touchback From Projected Screen
6. **FAQs and Troubleshooting**
    1. How to use remote control to disable touch feature
    2. How to capture log
7. **Remote Manager**
    1. Introduction
    2. Install Software
    3. Add/Remove Group Device
    4. Add Devices via Auto Discovery
    5. Configure Device Setting
    6. Remote Power On/Off (RDM)
    7. Update Firmware
    8. Configure Moderator Credentials
    9. Server mode – Remove Manager DB Server
    10. Use Remote Manager for large deployment
8. **Accessories**
    1. Mobile Stand VKST41