

Remote Control (X900)

Model name: NC-X900


Remote Control Pairing

NC-X900 is using RF remote control. Before you can use the remote control, you must pair it with the main unit.









Step1. Power on the main unit.

Step2. With the remote control in range of the main unit, **press and hold** the **Volume +** and **Volume –** buttons simultaneously for 2 seconds. The left LED will light up and start blinking.

Step3. Once the LED stops blinking and stays constantly lit, pairing is complete.



Function Description

Icon	Description	Icon	Description	Icon	Description
	Mode Switching (Presentation- Signage)		Volume +/-		Go-Back
	Power		Navigation		Home
	Mouse Click(Left Click)	OK	Confirm		Recent Apps