

Settings

This article is applicable to NovoConnect series:

NovoCast, NovoPro, NovoEnterprise, X300, NovoDS mini, NovoDS, NovoDS4K

*A USB mouse will be necessary for the following operation.

Wi-Fi


- Wi-Fi Hotspot Mode
- Wi-Fi Client Mode
- Wi-Fi Off

Display

- Resolution
- Screen scaling
- HDMI-CEC
- Sleep Timer

Settings Menu

User can expand the **Settings Menu** by click the NovoConnect logo at the bottom-right of **Home Screen**. The pictures below explain the details of Settings Menu.



General Settings

It contains advanced device settings, including Network, Security, Language, Date & Time, and also the other device information.

Settings

General Settings

Firmware Upgrade

Settings Lock

Screen-Cast Configuration

Log Download

Firmware Upgrade

User can check* the updates, or do online update* when the updated is available.

**Checking updates or online updating will need Internet connection.*

Settings

General Settings

Firmware Upgrade

Settings Lock

Screen-Cast Configuration

Log Download

Settings Lock

When this option is enabled, **Password** will be necessary to input for entering the setting menu or changing the settings. The password allows alphanumeric characters: 0-9, A-Z, a-z.

Settings

General Settings

Firmware Upgrade

Settings Lock

Screen-Cast Configuration

Log Download

Configure Settings Lock

- Disable Lock
- Enable Lock

Apply

Cancel

Screen-Cast Configuration

User can enable or disable the screen casting function from here, and also the connection security options.

Settings

General Settings

Firmware Upgrade

Settings Lock

Screen-Cast Configuration

Log Download

User can mirroring their **Android** or **iOS** devices by enabled the following options.

- **Enable Google Cast**
- **Enable AirPlay**

Screen-Cast Configuration

- Enable Google Cast
- Enable AirPlay
- Enable AirPlay Password
- PIN Required

Apply

Cancel

▪ Enable AirPlay Password

User can enable this option to prevent any unexpected connection or interruption by others when mirroring with **AirPlay**.

▪ PIN Required

PIN Code is random generated, and will be the same value as **AirPlay Password.*

When this option enabled, user can't connect to NovoConnect without the specified **PIN Code** shown on the **Home Screen**.

Log Download

To enable this option, user can download the System Log directly*.

**Both user's computer and NovoConnect device must under the same networking.*

Settings

General Settings

Firmware Upgrade

Settings Lock

Screen-Cast Configuration

Log Download

Log Download Settings

Enable Log Download

Apply

About

User can check the current software version and software compatible chart here.

Others

Enable or Disable showing the Meeting ID or QR Code on Home

Screen.

- Meeting ID
- QR Code
- Session Info

User can check the paired Launchers here.

- Paired Launcher Units

User can change the Home Screen by uploading specified Pictures or Videos via Remote Manager.

- Customize