

Supported USB Cameras

The following USB cameras are supported by **NC-X700**, **NC-X900**, **NovoDisplay** and **NovoTouch**.

Brand	Model	Device Type
AVer	CAM340+	Camera + Microphone
AVer	VB130	Camera + Microphone + Speaker
AVer	PTC310UV2	Auto Tracking Camera + Speaker
AVer	PTZ310UNV2	Streaming PTZ Camera + Speaker
BOSE	VB1	Camera + Microphone + Speaker
Logitech	Meetup	Camera + Microphone + Speaker
Logitech	Group	Camera + Microphone + Speaker
Logitech	C922 Pro	Camera + Microphone
Polycom	X30	Camera + Microphone + Speaker