BYOM Installation and Activation

Installation

Step 1. Update the firmware of your NovoConnect device (V4.5 or above)

- There are several ways to perform firmware update. Please refer to the corresponding document for details.

Step 2. Connect USB camera / microphone / soundbar to your Novo device

Step 3. Download and install the BYOM driver for your Windows and/or MacOS computers.

- Please visit www.launchnovo.com for details.

Activation (First-Time Usage)

You will need to activate the BYOM feature on your Novo device for the very first-time usage. There are two ways to do so.

(1) Activation from your Novo device. Click on the main menu button and then **BYOM**. Follow the on-screen instructions to enter your **license key** or click **Free Trial** to gain access.



(2) Activation via Remote Manager software.

Step1. Select the Novo device on the home screen and click on setting icon.



Step 2. Click on **“Activate”** icon



Step 3. Enter your license key and then click on **“Apply”** icon to active your BYOM service.



Step 4. Your BYOM service has been activated.