

# 4.1 NT Settings


NT Settings contains **Network, Display, Software Upgrade** and **Device Settings**.

The article will explain the main functions of NT Settings and guides you how is it working.


## How to enter the NT Settings

*\*User will need to connect a Wired/ Wireless Mouse to NovoConnect for the following operation.*


- Click **“Presentation”** at the bottom-left of the screen
- Then click **“Settings”**



- Click **“Device Settings”** to enter NT Settings




# NT Settings Menu



## Wi-Fi Settings

**Wi-Fi Hotspot** mode is factory default setting, you can change it to **Connect to Wi-Fi** (AP-Client), or **Turn Wi-Fi off** (Radio off).



Wi-Fi Hotspot mode also provide “**LAN-Wi-Fi-Hotspot routing**”, It means, when this option is enabled, both the two network will be the same routing, if NovoConnect X700/ X900 connects both Wireless and Wired network.

### **Wi-Fi Frequency and Channel**

Wi-Fi HotSpot mode provide **2.4GHz** and **5GHz**, they have **11 channels** and **9 channels** respectively. **5GHz** and **Channel 40** is factory default setting, you can change the frequency and channel anytime.

## Select Channel

### 2.4 Ghz

CH 1

CH 2

CH 3

CH 4

CH 5

CH 6

CH 7

CH 8

CH 9

CH 10

CH 11

### 5 Ghz

CH 36

CH 40



CH 44

CH 48

CH 149

CH 153

CH 157

CH 161

CH 165

## Display

NovoConnect device supports the following outputs resolution:

### Resolution

- Auto
- 1280 x 720 (50Hz)
- 1280 x 720 (60Hz)

- 1920 x 1080 (50Hz)
- 1920 x 1080 (60Hz)
- 3840 x 2160 (30Hz)
- 3840 x 2160 (50Hz)
- 3840 x 2160 (60Hz)

# Display

Resolution    Scaling    Sleep Timer    Auto Reboot

Auto Config

720p 50Hz (1280x720)

720p 60Hz (1280x720)

1080p 50Hz (1920x1080)

1080p 60Hz (1920x1080)

4K 30Hz (3840x2160)

4K 50Hz (3840x2160)

4K 60Hz (3840x2160)

Apply    Cancel

**Scaling**



# Display

Resolution

Scaling

Sleep Timer

Auto Reboot



OK

**Sleep Timer**



# Display

Resolution

Scaling

**Sleep Timer**

Auto Reboot


- Do not enter sleep mode
- Enter sleep mode after idle-timeout
- Always on

Apply

Cancel

**Auto Reboot**






## Upgrade

User can check the current software version here. And also if the updates available, user can perform online upgrade by tapping "**Check for updates**". (Internet connection is needed for the process)

## General Settings



Here user can also perform the following settings:

- **Change the Device Name**

User can change the device name for easily identifying the device or the location where the device is. This changing will also be displayed on the Home Screen of NovoConnect device.

- **Enable or disable Setting Lock**

Use for connecting other apps or devices to NovoConnect device.

API service can be enabled or disabled after Setting Lock is

enabled.

- **Enable or disable Log Download**

Allows the log file to be downloaded for debugging.

- **Advanced (Android Device Settings)**

To change **Date, Time, Time Zone, Input Method, Language, Google Account**. Or advanced settings for system management or maintenance, e.g. **Apps management, System Security, Networking Credentials**, etc.

