
2.7.3 Remote Media



- 1. In the **Duration** field, select how long each media file in the remote storage directory will be displayed in the layout item/box.
- 2. In the View Type field, select one of the following options to configure how the image/video will fit into the layout box:
 - •Stretch to fit region Stretches smaller images/videos horizontally so that they fit into the layout box.
 - Fit region Scales the images/videos so that the full image fits into layout box.
 - •Scale to fill region Scales up smaller

images/videos until the layout box is completely
filled.

- 3. In the Others field, check any of the following options:
 - **Detect Picture Orientation** Makes automatic corrections to the picture orientation.
 - Stretch Video to Fill Region Stretches the video horizontally to fill the size of the box.
 - **Set as audio source** Make the display broadcast the audio from the media file.
- 4. Enter the login settings for the storage service you are using, and then in the **Refresh Period** field select how often you want DS Playlist to check for new files stored in the path given.
- 5. Click **Save** to finish configuring the media settings.