# 5.1 NT Settings

NT Settings contains Network, Display, Software Upgrade and Device Settings.

The article will explain the main functions of NT Settings and guides you how is it working.

### How to enter the NT Settings


\*User will need to connect a Wired/ Wireless Mouse to NovoConnect X500 for the following operation.

• Click "Presentation" at the bottom-left of the screen

Then click "Settings"

	Presentation 🧲	
	Settings 2	C. A
	About	
	Restart	
		7 Maint
1	Presentation	Signage

### Click "Device Settings" to enter NT Settings



# NT Settings Menu

Wi-Fi	Display	Upgrade	General
Ô			lił

### Wi-Fi Settings


Wi-Fi Hotspot mode is factory default setting, you can change it to Connect to Wi-Fi (AP-Client), or Turn Wi-Fi off (Radio off).

<	Wi	-Fi	
	<ul> <li>Enable Wi-Fi Hotspot</li> <li>Channel 5 GHz-CH 40 </li> <li>Enable LAN-Wi-Fi-Hotspot routing</li> <li>Connect to Wi-Fi</li> <li>Turn Wi-Fi off</li> </ul>		
	Apply	Cancel	

Wi-Fi Hotspot mode also provide "LAN-Wi-Fi-Hotspot routing", It means, when this option is enabled, both the two network will be the same routing, if NovoConnect X500 connects both Wireless and Wired network.

#### Wi-Fi Frequency and Channel

Wi-Fi HotSpot mode provide 2.4GHz and 5GHz, they have 11 channels and 9 channels respectively. 5GHz and Channel 40 is factory default setting, you can change the frequency and channel anytime.



## Display

NovoConnect X500 supports the following outputs resolution:


#### Resolution

- Auto
- 1280 x 720 (50Hz)
- •1280 x 720 (60Hz)


- •1920 x 1080 (50Hz)
- •1920 x 1080 (60Hz)
- 3840 x 2160 (30Hz)
- 3840 x 2160 (50Hz)
- 3840 x 2160 (60Hz)

<	Display		
Resolution	Scaling	Sleep Timer	Auto Reboot
	Auto Config		
	720p 50Hz (1280x720)		
	720p 60Hz (1280x720)		
	1080p 50Hz (1920x1080)		
	1080p 60Hz (1920x1080)		
	4K 30Hz (3840x2160)		
	O 4K 50Hz (3840x2160)		
	─ 4K 60Hz	(3840x2160)	
Apply		Са	ncel
1 <u>-</u>			


Scaling



Sleep Timer




Auto Reboot



### Upgrade

User can check the current software version here. And also if the updates available, user can perform online upgrade by tapping "Check for updates". (Internet connection is needed for the process)

## **General Settings**



Here user can also perform the following settings:

#### - Change the Device Name

User can change the device name for easily identifying the device or the location where the device is. This changing will also be displayed on the Home Screen of NovoConnect X700/ X900/ X500

#### Enable or disable Setting Lock

Use for connecting other apps or devices to NovoConnect X700/ X900/ X500.

API service can be enabled or disabled after Setting Lock is enabled.

#### • Enable or disable Log Download

Allows the log file to be downloaded for debugging.

Advanced (Android Device Settings)

To change Date, Time, Time Zone, Input Method, Language, Google Account. Or advanced settings for system management or maintenance, e.g. Apps management, System Security, Networking Credentials, etc.

≔	
<	
>	