


4.1.1 Sleep Timer


Configuring a Sleep Timer

Step1. In the NT Settings menu, tap **Display**.



Display settings

Step2. In the **Display** menu, select **Sleep Timer**.




Modes of Sleep Timer

Step3. The **Sleep Timer** menu will show the following options:

- Do not enter sleep mode
- Enter sleep mode after idle timeout

This item includes the following options to select: **5 minutes / 10 minutes / 15 minutes / 30 minutes / 1 hour**

- I. After you've selected the option you want, tap **Apply**.
- II. Return to the display's home screen.
- III. Once the home screen has been idle for the designated amount of time, the display will enter sleep mode.




Timer selection


- Set power-on schedule

Allows you to set the days and time period each week when the display will be constantly on.

- i. After you've selected the days and time period you want, tap **Apply**.
- ii. Return to the display's home screen.
- iii. Once the designated time is past, the display will enter sleep mode.



Create a schedule



Successfully set up message

