




# 2.7 Use Remote Manager for installation

Launch **Remote Manager** software under the same local network with Novo device.

Go to the left top corner, click **+Device** > Input the Novo device's IP address to add the device into Remote Manager table.




One the device list, click the device you want to configure, then click  to go to setup.




| ... | Device Name | IP Address   | rou | Activity | Device Type            | Firmware Version | WI-FI Mac Address |
|-----|-------------|--------------|-----|----------|------------------------|------------------|-------------------|
| 1   | Novo-DE271  | 10.136.5.20  |     | Idle     | NovoTouch EK-II Ser... | v4.1.0.1024      | 50:2B:73:DD:13:0A |
| 2   | Novo-D831G  | 10.136.5.126 |     | Idle     | NovoPro                | v2.7.4.422       | 04:E6:76:C3:33:78 |
| 3   | Novo-16016  | 10.136.5.17  |     | Idle     | NovoTouch LK Series    | v3.1.1.284       | 10:D0:7A:71:BB:47 |


IT can control the devices remotely, such as setup device name, remote upgrade, change system language and time zone, download log file remote for troubleshooting and so on for individual Novo device.




General settings



Network settings



Security settings



Settings for System Language, Time Zone, NTP Server, Log File Download, Remote Reboot, Upload Config File.